


EXTERNAL DIMENSION



PIN CONNECTIONS

PIN NO	1	2	3	4	5	6	7	8	9	10
SYMBOL	<i>leda</i>	<i>ledk1</i>	<i>Ledk2</i>	<i>Im0-IM3</i>	<i>Im0-IM4</i>	<i>Im0-IM5</i>	<i>Im0-IM5</i>	RESET	VSYNC	HSYNC
PIN NO	11	12	13	14	15	16	17	18	19	20
SYMBOL	DOTCLK	DE	DB23	DB22	DB21	DB20	DB19	DB18	DB17	DB16
PIN NO	21	22	23	24	25	26	27	28	29	30
SYMBOL	DB15	DB14	DB13	DB12	DB11	DB10	DB9	DB8	DB7	DB6
PIN NO	31	32	33	34	35	36	37	38	39	40
SYMBOL	DB5	DB4	DB3	DB2	DB1	DB0	D0	SDO	SDI	RD
PIN NO	41	42	43	44	45	46	47	48	49	50
SYMBOL	D/C	CS	VDDI	VCI	GND	XR/SCL	YD/SDA	XL/INT	YU/RST	GND